Warranty Information

Wuxi Intenergy Co., Ltd. ("Company") warrants to the original purchaser that batteries, solar panels, and LED bulbs (collectively "Products") will be free from defects in material and workmanship under normal use for a period of one (1) years from the date of purchase. All other electrical components are covered for a period of one (1) year from the date of purchase.

In the event of a defect during the warranty period, the Company or its authorized dealers will, at their sole discretion, either repair the defective product using new or refurbished parts or replace the defective product with a new or equivalent product at no charge.

Note: After the expiration of the warranty period, repairs or replacements will be available at the customer's expense.

Safety Information

1. Use the iBox-DC100 indoors and keep it dry.
2. Do not immerse the unit in water.
3. For service or battery replacement, return the unit to the original dealer or place of purchase.
4. If condensation forms inside the unit, allow it to air dry naturally before use.
5. Keep the unit away from fire and extreme heat.
6. Avoid unauthorized disassembly, component replacement, or modification of software codes. The battery is not replaceable.
7. In case of malfunction, turn it off immediately. For further assistance, contact INTENERGY support or your local dealer.
8. Do not use the unit with damaged cables or plugs.

Intenergy Contacts

Wuxi Intenergy Co., Ltd.

Tel: +86(0)-510-88781862 Website: www.intenergy.cn

E-Mail: info@intenergy.cn

Address: No.49-1 Zhujiang Road, National High-Tech development Zone, Wuxi 2141000,JiangSu,China.

Warranty Cards

Manufacture Date: _____

Sale Date: _____

FileNo.: _____

iPower Mobile Series

Solar Home System

iBox-DC100



User Manual

Fully Charge and discharge the unit before its first use.

Legal Information

Copyright © 2025 Wuxi Intenergy Co., Ltd. All Rights Reserved.
No reproduction or transmission of any part of this document is permitted without the prior written consent of Wuxi Intenergy Co.,Ltd.

Get to know your iBox-DC400



1. ON/OFF
2. USB-C Input/Output Ports
3. Battery Capacity Display
4. LED Lights
5. USB-A Output Port
6. USB-A Output Port

Use your iBox-DC100



When using the product, press the power button first. The power display screen will turn on and show the current battery capacity.



Press the power button once to display the battery level on the screen. Press it twice to turn on the four LEDs, and press twice again to turn off the LEDs.



There are two ways to charge the battery.
One is to charge it during the day using the 30W solar panel we provide, and the second is to charge it using a charger with mains power. When charging, the ⚡ indicator on the display will flash.



The product has two USB-A outputs that can be used simultaneously.



What's in the Box



iBox-DC100
Mobile Power Box



Solar Panel 30W
(Packed separately)



5W DC Fan
(Packed seperately)



Documentation

Charge/Power your device



Specification

Model	No.	iBox-DC100
	Battery Capacity	102Wh
	Cell Type	Lithium
	Net Weight	0.56KG
	Dinmansion	50x50x125mm
DC Output	2*USB-A	22.5W/5V~12V
	1*USB-C	20W/5~12V
Input	Solar Charging	30W/Type-C
	USB-C Charging	20W/Type-C